FirePRO 300

Quick Start Guide

Image and Video Capture:

Press and Release to capture image. Press and Hold for 2 seconds to start video recording. Press and Release to stop video recording.

Power On/Off:

Press and Hold for 2 seconds to power on.

Press and Release to return to the default TI Basic mode.

Press and Hold for 3 seconds to power off.

°F/°C:

Press and Release to change from °F to °C.



Change Mode / Flashlight:

Press and Hold for 3 seconds to cycle through modes (TI Basic, TI Basic+, Survey mode).

Press and Release to turn the flashlight on/off.



300 Lumen Flashlight





320 x 240 Thermal Sensor





On-Screen Device icons:

- Mode indicator (TI Basic+ and Survey)
- 2. Overtemp indicator
- Spot temperature reticle (when TI Basic+ or Survey mode is enabled)
- 4. Battery charge status
- Spot temperature reading (when TI Basic+ or Survey mode is enabled)
- 6. Temperature color bar



- | > 75% charge remaining | > 55% charge remaining
- | > 25% charge remaining
 - < 25% charge remaining

(>5min remaing when flashing)







Training

Cleaning Instructions and Care: Clean the lenses and display using a lint-free cloth and commercial lens cleaning solution. Clean the camera housing using mild soap and warm water.

DO NOT USE SOLVENTS WHEN CLEANING THE PRODUCT

Imagery for illustration purposes only. Specifications subject to change without notice. Please visit support.thermal.com for the latest specifications and support.





